

HOW TO APPLY ZINGA?



Clean the Surface

BEST PRACTICE

High Pressure Washer with warm water or steam

OR

Remove any loose particles
Degrease with cloth with Zingasolv

Roughen the Surface + Dedust

BEST PRACTICE

Grit/Slurry/Sponge blasting to SA 2.5

OR

(Rotative) steel brush or bristle blaster

Mix ZINGA

BEST PRACTICE

Drill mixer

OR

With wooden stir stick

At least 2 minutes - No zinc residu on bottom

Apply

Brush natural hairs

Paint Gun conventional or airless

Thinning with Zingasolv

Short hair roller (not synthetic)

ZINGA Products

ZINGA unique = ZINGA in 2 layers

Grey finish

ZINGA Alu = ZINGA in 2 layers + Alu ZM in 1 layer

Aluminium finish

ZINGA duplex = ZINGA in 1 layer + Zingalufer in 1 layer + Topcoat

Finish in colour of choice

Systems

ZINGA unique

1. ZINGA
2. ZINGA

ZINGA duplex

1. ZINGA
2. Zingalufer
3. Topcoat

The good performance of ZINGA will be in direct relation to the quality of the surface preparation. Extra effort will result in a sustainable, long lasting protection of metal structures.